


# INSTRUCTIONS

## Bluebird Villa

BBV



[www.skmfg.com](http://www.skmfg.com)  
1-800-764-8688




### Parts:

- 1 Bluebird Villa body
- 1 Inspection/clean-out port cap
- 1 Floor mat
- 4 Snaps



The Bluebird Villa can be used as is, or you can add the floor mat to the bottom of the Bluebird Villa for added traction on the inside of the Villa..


OPTIONAL: To add the mat, spread it evenly on the floor inside the Bluebird Villa. This is done through the Inspection/Clean-out Port.



Attach the Floor Mat using the four Snaps. From the inside of the Bluebird Villa, push each snap through a corner of the Floor Mat and through the four holes in the bottom of the Bluebird Villa.

### Hanging options:

- Attach the Bluebird Villa to a wooden fence or post (sold separately).
- Use S&K's T-Post Mount (TPM) (shown on right, sold separately).
- Use S&K's BHA to mount to a Tri/Quad-Tel Pole (Pole and BHA sold separately).



S&K Manufacturing, Inc.  
1001 Liberty Industrial Drive  
O'Fallon, Mo 63366  
[www.skmfg.com](http://www.skmfg.com)  
1-800-764-8688  
Fax: 636-272-4044

**When attracting bluebirds, place the BBV 5- to 10- feet above the ground, secured to a post or pole.**  
**When mounting multiple BBVs, mount them 150 feet apart.**

**All adapters for the BBV can be found at**  
[www.skmfg.com](http://www.skmfg.com)

**IF ANY ITEMS ARE DISCOVERED MISSING, CALL 1-800-764-8688**  
**WWW.SKMF.COM**