

INSTRUCTIONS


SKW



S&K WINCH

052009v2

Use With S&K ELP Pole, RP19 Pole or SP2 Pole



- Winch assembly
- Steel Cable with Hanging Hook

S&K Manufacturing, Inc.
1001 Liberty Industrial Drive
O'Fallon, Mo 63366
www.skmfg.com
1-800-764-8688
Fax: 636-272-4044





1. Assemble winch by placing handle on - tighten. Attach clamps to back of winch with machine screws and nuts.



2. Place the winch on the pole at the location you want to operate it. Make sure the winch is placed on the pole with the top facing the sky. As shown in photos. We recommend the winch be placed somewhere between two (2) feet and four (4) feet above the ground.



3. Insert and tighten the bolts into the back of the winch and into the clamps. Now place clamps on pole and bolt onto pole. Screw the self-tapping screws through the clamp and into pole - 2 self-tapping screws on each side of the clamp.



4. Unwind the cable from the winch spindle. Take note of how the cable is secured to the winch. Before removing the cable from the side wall of winch, mark the cable (use a black marker or tape) at the point where the cable first enters the side wall (See arrow). (Approximately 13 inches of cable is required to wrap around the sidewall of the winch to secure the cable.



For The Fountain Rack




5A. Run the non-hooked end of cable up through the Fountain Rack (which should be on the lower part of the EasyLift Pole). Continue with the cable over the pulley wheel in the EasyLift Pulley, and down through a different opening of the Fountain Rack. Pull the cable through until the hooked end of cable is touching the hanging block.

For the FR8, MHR, MGR12 Using S&K RP19 Pole or SP2


**BE SURE TO HAVE THE CABLE GO STRAIGHT UP THE POLE -
DO NOT ALLOW IT TO WRAP AROUND THE POLE!**




5B. Put pulley topper on top of the straight pole. This may require removing the top two sections of a previously installed S&K Pole. Run the non-hooked end of the cable over the pulley and pull through. Next take the same end of the cable through the rack you are hanging. Attach the Cables Hook to the Holding Bracket on the rack.



6. After running the cable up and through the Pulley and the product being supported on the pole, take the non-hook end of the cable and run it into the winch as shown. (Note: The cable goes behind the two bars above the winch's spindle, as shown.)



7. Restring cable by first pulling the cable through a sidewall opening until the black mark (made in Step 4) is at the opening. This will give the correct amount of cable to secure it to the winch.



8. Restring cable by "walking" it around the four openings in the sidewall of the winch spindle. Loop it in and out of the four openings until it ends up with a small length of cable OUTSIDE the winch wall.

9. While keeping the cable taught, begin winding the cable onto the winch with the crank. As the cable tightens, the product on the pole will move upward. When it is in place, slip the "lock" on the left of the winch in place.

S&K Manufacturing, Inc.
1001 Liberty Industrial Drive
O'Fallon, MO 63366

SK
&
MANUFACTURING

www.skmfg.com
1-800-764-8688